

# EM EQUIPMENT MANAGER

## RELEASE NOTES

VERSION 1.2.0

JULY 2025

### Confidentiality Notice

This document contains confidential information and trade secrets of Bourque Logistics. It is intended solely for the use of authorized Bourque licensees. Unauthorized use, distribution, or disclosure is strictly prohibited.



## ❖ NEW FEATURES

- Asset and Lease Assign | Future Dating Capabilities are now available for Asset and Lease assignments.
- New User Roles Added
  - EQ\_ADMIN\_NO\_LEASE: Full Rights to all Equipment Maintenance, Asset & Fleet Assignments. **\*\* No rights to Lease Rider/Rental data**
    - *This is replacing EQ\_ADMIN*
  - EQ\_ADMIN\_WITH\_LEASE- Full Rights to all Equipment Maintenance, Asset & Fleet Assignments **and Lease Rider/Rental data.**
    - *This is replacing EQ\_LEASEMAINT*
- Expiration Dates expire at 23:59:59 on the date defined.
- Equipment Type - Car Type | Car Type selection is restricted based on the selected Equipment Type
- Equipment Module | SYSTEM LEASE RIDER FASTRAC | Added additional columns to the template.
- Mechanical Fields | Added Builder Lot Code as a permanent mechanical field under grouping RALL
- Rail Equipment Current Dates | Added a New System FASTRAC in Called SYSTEM TANK REQUALIFICATION
- Rail Equipment Current Dates | Added Install Dates for Components to the grid and Get Data
- Mechanical Fields | Changed the display name from "Requalification Date" to "Tank Requalification Date"
- Equipment | Changed the location of Equipment Type and Car Class fields in the Equipment detail.
- Equipment | 4-digit years are now utilized throughout the application
- Equipment - Components | Added the ability to remove a component from a car
- Equipment | Added Compartment section to Equipment details
- Equipment | Added Edit Icon to Fleet Assign section of Equipment details
- Lease Rider Added the ability to update the Lease Type on a Lease Rider with no cars assigned.
- Reference Objects | Mechanical Fields | Changed the field name Tare Weigh Date to Scale Tare Weigh Date
- Equipment | Added a default Mechanical field added called Service Equipment for Mechanical Display grouping RALLTC
- Equipment | Changed the field titled Car Class to Car Type
- Equipment | Added Term Renewal Date to Lease Rider Section and included that field in the following System Fastracs: System Car Lease/Sublease, System Car Profile Lease, and System Car Profile Sublease
- Lease Rider | Riders with a zero rental amount are now allowed.
- Lease Rider | Changed the name of Lessor No. field to Lessor Name
- Asset Assign | When cars are added, UMLER lookup will occur for car owner and adjust the Car User ID to 5 if the car is public.
- Asset Assign - Lease & Sublease/Financial Changed the names of fields *Lease Effect date* and *Lease Expire Date* to *Assigned to Rider Date* and *Removed from Rider Date*
- Asset Assign - Lease & Sublease/Financial | Removed the field Lease From Available Date from the Lease and Sublease/Financial sections
- Asset Assign - Lease & Sublease/Financial | Removed the Off Hire and ERP Information sections from the Lease/Financial and Subleases sections of Asset Assign for Rail Equipment/Clients
- Mech Field Dates | Created a default component called Stub Sill in RALLTF category.

- Mech Field Dates | Added a Requalification Due field to the Rail Equipment Current Dates grid and Get Data section
- Equipment | System FASTRAC | Added three new FASTRAC's: SYSTEM CAR PROFILE LEASE DETAIL, SYSTEM CAR PROFILE SUBLEASE DETAIL, SYSTEM CAR LEASE/SUBLEASE DETAIL
- All Required Fields are now notated with an asterisk
- All Read Only Fields are now notated with a grey background

## ❖ **BUG FIXES**

- Lease Rider | When adding a new rider, populate the Lease Type based on the Lessor Fact.
- Equipment | Add Equipment | When user clicks Add to add a piece of equipment, EM will now scroll down to the detail section.
- Equipment | Add Equipment - Compartment | Users should not be able to use numbers greater than 6 or use the number "0" in the Num Compartments field when adding or updating a car.
- Equipment Component | Add Component | When the user adds a component with an Install more than 50 years ago 2 error messages occur. This is now showing correctly
- Equipment Component | The Equipment Component grid is now loading.
- Reference Objects | Grid is now loading properly focused at the top of the screen.
- Lease Rider | When attempting to add a new Asset Status to a piece of equipment (LSS to LSS Status with a new rider), system was providing invalid options. This is now corrected.
- Reference -Components | Delete of a component should not be allowed if the component is associated with a piece of equipment